

1. Feature:

- 1. Ideal design for makeup, cosmetic, nail beauty and so on.
- DC power supply.
- 3. Air Delivery Adjustable.
- 4. 360 degree circumvolve airbrush holder, for your convenient work.
- 5. 6 Different Color Case for The Personalized Choice.
- 7. Low noise.

6. Oil free, piston type, no air polluted.

2. Specification:

Type: Piston type compressor

Motor: DC 12V

Currency: 1.6A

Air Flow: 10L/Min

Working Pressure: 2~28 PSI

Weight: 1.0KG


Dimension: 130X105X72mm

Suitable for airbrush with nozzle 0.2~0.3mm(Feed type: Gravity).

Fully charge time: around 2.5 hours(power auto cut off when fully charge)

Working time after fully charge: 1.5 hours(stop for a while after every 30 min's working).

6. Air Compressor Structure:



A: Hanging Ring B: Power cord(AS-204); Power Jack(AS-204A)

E: Power switch

- C: Air Delivery Regulator
- D: Mini Holder slot
- F: Air outlet socket
- G: Nozzle replacement joint
- H: Hose connector

7. Spare Part List:




PARTS NO.	DESCRIPTTON	
#1	MASTER DEVICE AS-204A(BATTERY IS INSIDE)	
#2	CLIMB-BOLT	
#3	MINI HOLDER	
#4	CONNECTOR OF THE AIRBRUSH HOLDER	
#5	HOLE-THROUGH AND STOPPER-PICK PIN	
#6	BATTERY CHARGER	
#7	AIRBRUSH HOLDER	
#8	REPLACEABLE NOZZLE BD-350	
#9	SILICONE HOSE	
#10	AIRBRUSH BD-350	

3. Application Field:

Airbrush makeup system BD-350, which has many patents, professional products for the cosmetic use, six different of colors are available for you.

4. Operation Directory:

- 1. Connect the one side of air hose into the compressor outlet, and the other side to the airbrush. Afterwards plug in the air compressor.
- 2. Turn on the switch, then press down the airbrush button for the normal working.
- 3. This compressor could adjust the output air through the regulator.
- 4. The compressor can work under the pressure, and continuous working.
- 5. The mini holder could circumvolve in 360 degree for the convenient usage.
- 6. When you need to charge, insert the plug of the charger to the current source, Red light means charging, green light means the charging is over.
- 6. Different Methord Usage on different circumstance:



7. When you need to change the nozzle of the Airbrush, Just press the button H, then










8. Please use the pin(5,HOLE-THROUGH AND STOPPER-PICK PIN) to make the top hole throughly and pick up the stopper of the inside plastic bottle.



Function 1





at least one time every three months prevent automatic discharger.

10. This airbrush compressor suitable for indoor use only, to prevent health damage,

5. Safety Requirement For User

1. Use the correct charger for li ion battery.

2. Don't reverse charger battery.

alkaline and zinc carbon.

never use at high temperature, wet location! 11. The product must used in dry, indoor locations. Do not spray noxious, flammable,

3. Don't short-circuit battery, permanent damage to battery may result.

4. Don't incinerate or mutilate battery, may burst or release toxic material.

5. Don't solder directly to cells or battery, please store battery in a cool dry place.

6. Don't mix battery with other battery type, or battery of a different chemistry, such as

- explosive material.
- 12. Unplug a battery by holding the connector it from the device.
- 13. If don't use this product in right way, it will damage the airbrush compressor, battery, or hurt user!
- 14. If there is something unusual happens, please disconnect the device and power supply immediately.
- 15. If any accessory is damaged, please take it to wholesaler or professional repair shop, do not try to repair by oneself.
- 16. Please keep the airbrush compressor and battery in clean, dry and do not expose the product or its accessories in the sun or to the temperatures high than 35°C.
- 17. The product is not a toy and must be kept out of the reach of children, there is an electric shock hazard if connect the power plug in a wrong way.

(1). Lay on the dest

(2). Clamp by the Hook